

HEXMAT Absolute

User Manual

Thank you for purchasing our product!

Please read these instructions carefully before using your new HexMat Absolute!

1. Place the isolator mat directly onto your turntable platter, ensuring the magnets in the centre are facing upwards
2. Verify that the vertical tracking angle (VTA) is correctly set on your turntable. If you are unfamiliar with this procedure, please consult an expert to prevent damage to your cartridge or records
3. The magnets in our products are directional and fully shielded to avoid interference with nearby devices, such as cartridges or tonearms, when the Absolute clamp is in use
4. When a vinyl record is placed on the isolator, install the Absolute clamp.
5. The Absolute clamp must always be used during playback.
6. After stopping the turntable platter, remove the Absolute clamp by gently lifting it with your fingers. Avoid twisting or bending the clamp during removal.
7. Do not attempt to change records or flip sides while the platter is spinning, as this may cause damage
8. Do not store the clamp on electrical devices
9. Do not close the magnets without a vinyl record

Please note:

- Do not attempt to open or disassemble the product.
- Keep the product in a dry place and avoid storing it under direct sunlight.
- The warranty does not cover damages resulting from misuse or accidental harm to the product.

If you have any questions or encounter issues while using the product, feel free to contact us via email at info@hexmat.net.